



Product 511848



511848 Passive holder with tilt swivel Adjustable holder. Fits devices with or without skin/case, with height 120-150 mm, max thickness 25 mm.

Adjustable passive holder with tilt swivel for devices with or without skin/case. This holder is crash tested and approved for use with device without skin/case on Brodit's headrest mount. Keep your device in a holder in your car and you will always have it within easy sight and reach. Safe, neat and convenient!

Measure your device/skin/case and compare with the holder specifications to choose the right product for you. This holder fits for devices with or without skin/case with the height 120-150 mm and maximum thickness 25 mm.

You can attach a charging cable to your device in order to get charging while in the holder. The holder is equipped with a tilt swivel and can easily be adjusted in order to avoid light reflection. Tilts 20° and swivels 360°. The upper and lower parts of the holder have padded cushions for protection against sliding and scratching. It is easy to place the device in the holder, and to take it with you when leaving the car. Mounting plate 42x50 mm with predrilled AMPS-holes +2x3,5 mm centered holes. Made of high grade black ABS/Acetal plastic. Made in Sweden

Crash tested:

This adjustable holder is crash tested according to standard for car seats (ECE R17). The crash test applies for a tablet that weighs 490 g. The tests have been performed on one seat with invisible headrest pins (type Volvo etc.) and one seat with visible headrest pins (type Ford etc.) in the forward and rearward directions. The adjustable holder keeps the tablet in place during all executed tests.

Dimensions: 145 x 129 x 69 mm (W x H x D mm)

Weight: 157 g

Important information:

Tablets should not be installed onto a car's dashboard. They may block the view or key controls and the ProClip is designed for installation of smaller devices (phones), not for large devices (tablets). If you want to place a tablet onto the car's dashboard, each combination of tablet-car must be examined in detail by you in order to determine if such an installation is possible in the specific case. Consideration should be given to the position and how firmly the ProClip is in place, as well as the size of the tablet you wish to use. Brodit will not give any recommendations for such installations. An installation of a tablet onto a vehicle's dashboard is always done on the customer's own responsibility. Brodit recommends to use tablets in a holder on the car's headrest, installed onto a Brodit headrest mount.

EAN: 7320285118485

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.

2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Tighten the screw until the holder is firmly in place, but still can be adjusted.

3. To place the device in the holder: Place the upper part of the device under the upper part of the holder. Press upward so the upper part of the holder slides upwards. Press the lower part of the device forward so the device is placed straight in the holder. Stop pressing upward so the upper part of the holder slides downward and rests on the device. Press downwards **HARD** on top of the holder, in the same time tighten the wingnut on the back of the holder **FIRMLY**. **IMPORTANT:** It is very important to press downward **HARD** on top of the holder and to tighten the wingnut **FIRMLY** so the device is properly held in place in the holder.

To remove the device from the holder: Loosen the wingnut on back of the holder. Press the device upward so the the upper part of the holder slides upward. Lift the device downward and out of the holder.

4. The holder is in place.
